



NOTES:

1. SAMPLE POINT SHOULD BE A SERVICE LINE OR FIRE HYDRANT IF POSSIBLE.
2. AFTER SAMPLING IS COMPLETED AND APPROVED, SHUT OFF CORP. STOP, REMOVE TUBING, PLUG WITH BRASS PLUG AND LOCATE FOR RECORD DRAWINGS.
3. MOUNT METAL OR PLASTIC TAG INDICATING "SAMPLE POINT - DO NOT TURN OFF"

## SAMPLE POINT DETAIL

DSGN.	
DRW.	MES
CK.	ML



SOUTH MARTIN REGIONAL UTILITY (SMRU)

### CONSTRUCTION STANDARDS AND DETAILS

DATE APPROVED	AUGUST 2016
DRAWING NUMBER	WS 07